


III. Panel specification and connecting drawing as follows:



IV. Warning:

1. Supply voltage of this product is DC12V never connect to DC24V or AC220V.
2. Never connect two wires directly in case of short circuit.
3. Lead wire should be connected correctly according to colors that connecting diagram office.
4. Warranty of this product is one year, in this period we guarantee replacement or repairing with no charge, but exclude the artificial situation of damaged or overload working.

Super Easy Installation!

Just plug the power supply into the controller, put the receiver eye somewhere visible to remote, and plug the lights into the controller. The controller is the unit in the picture above next to the remote.

<http://www.BarLighting.com>